

Algo 8186 SIP Horn speaker Device Registration with CUCM 12.0


Configurations in CUCM

For registering Algo 8186 sip horn speaker in Cisco Unified Communications Manager configure:


- 1. End User in CUCM
- 2. Add a new Phone and associate with the end user created.
- 3. Provide the end user details in Bria 5.

Configuration of End user in CUCM


Navigation: User Management >> End User




1. Select Add New



- 2. User ID: 7002 (which is used in this example)
- 3. Password: <Password>
- 4. PIN: <PIN>5. Last Name: User



- 6 Digest Credentials: 123456 is used in this example.
- 7 Confirm Digest Credentials: 123456 is used in this example.
- 8 Save the configuration.



Configuration of Third-party client

The following procedure describes the configuration of third-party client on CUCM.


Navigation: Device >> Phone



Select "Add new"




In "Add a New Phone" page, Select Phone type as Third-party SIP Device (Advance).




Enter the following details in "Phone Configuration" page:


- 1. MAC Address: 123456ABCDEF (used as an example)
- 2. Device Pool: Select Default.
- 3. Phone Button Template: Third-party SIP Device (Basic).
- Owner: Select User
- 5. Owner User ID: bria 1 (Select corresponding End User created)




- 6 Device Security Profile: Third-party SIP Device Basic Standard SIP Non-Secure Profile
- 7 SIP Profile: Select Standard SIP Profile.
- 8 **DIGEST User**: Select the End user created.




- 9 Save the Configuration.
- 10 Configuring Directory Number by Selecting the Line under "Association" and provide the Directory Number for both page and ring extension.



11 Give the directory number for page extension as 7002 as an example




12 Give the directory number for page extension as 8025 as an example



Also associate the End user to the Line



Select the associated end user




Algo 8186 sip Horn Speaker Configuration

Enter the application webpage (ip address) using default password


Welcome to the Algo 8186 SIP Horn Control Panel
Setting up your SIP Horn:
Step 1: Configure your SIP Horn
Log in with the default password and use the Basic Settings pages to set up the basic information.
Step 2: Check network settings (Optional)
Use the Network page under the Advanced Settings tab to change network settings. The default setting for the device is to obtain administrator if you plan to assign a static IP address, Mask, and Gateway to the device.
Step 3: Secure your SIP Horn (Optional)
Use the Admin page under the Advanced Settings tab to change the administrator password. AChanging the password is extremely important if the device is directly connected to a public network.
Step 4: Register your SIP Horn (Optional)
Please register your product using the link below:
http://www.algosolutions.com/register
Registration ensures your access to the latest upgrades to this product and important service notices.
Login
Password (default: algo) Login


- 1. Enter SIP domain: CUCM IP address with the port number
- 2. Ring/Alert mode : select the monitor mode
- 3. Ring extension: ring extension dn (it is used for ring notification)
- 4. Authentication ID: End user authentication
- 5. Authentication password : End User pin
- 6. Page extension: page extension dn (it is used for page dialing and talk back facility).
- 7. Authentication ID: End user authentication
- 8. Authentication password: End User pin



Click **Save** to save the configurations.

Check the status on the webpage after the configuration.





The two extensions page extension and ring extension is successfully registered.